## Assignment:

#### **CREATING A FAILOVER**

## Task description:

On the DHCP1 server, which is a member of the ita.lan domain, install the DHCP server role and configure the DHCP server with a scope address range of 192.168.201.101 to 192.168.201.151.

On the DHCP2 server, which is also a member of the ita.lan domain (the server's IP address is 192.168.201.2), install the DHCP server role. Don't forget to authorize the servers in Active Directory.

You need to implement a DHCP failover.

A replication failover must be performed using the following parameters:

- *Partner server: 192.168.201.2*
- Relationship Name: NameSurname (here you need to set your first and last name)
- Maximum Client Lead Time: 5 minute
- *Mode: Host Standby*
- Role of partner server: Standby
- Address reserved for standby server: 20%
- Shared secret: 12345DHCP

On the DHCP2 server, in the DHCP console, under the IPv4 node, verify that Scope First Name is configured. Then, on the CLT-1 client computer (it must be logged on as a domain administrator), set the network adapter to automatically search for an IP address. Check the IP address of the DHCP server. After that, on the DHCP1 server, stop the DHCP service and restore the IP address on the CLT-1 client computer.

Submit the solution in the form of a text document, in which you will gradually describe the stages of solving the task according to the step-by-step system. Additional requirements, in addition to the text solution, attach screenshots of the following stages of solving the task:

- 1. presence of Scope NameSurname in the IPv4 node on the DHCP2 server after failover setup;
- 2. The IP address received by the CLT-1 client immediately after the failover was set;
- 3. The IP address that the client received immediately after the IP address was restored, after a failover was initiated."

Course: Network Server Services Module: DHCP Implementation

**Student**: Jovan Ljušić

# Content:

- 1. Server Installation
- 2. Managing DHCP
- 3. Creating a Failover
- 4. Post failover settings

#### SERVER INSTALLATION


This document presents a step-by-step approach to solving a specific task, outlining the methodology, execution, and expected outcomes. By following the instructions, the reader will gain hands-on experience in applying technical concepts to practical situations, reinforcing both theoretical knowledge and problem-solving abilities.

The structured approach ensures that each step is clearly defined, making the process easy to follow and implement in professional environments.

At the very beginning of this task, I started with the creation of a virtual machine. In this task, two servers are provided with certain settings as each step will be illustrated.

On the DHCP1 server, which is a member of the ita.lan domain, install the DHCP server role and configure the DHCP server with a scope range of 192.168.201.101 through 192.168.201.151.


On the DHCP2 server, which is also a member of the ita.lan domain (the server's IP address is 192.168.201.2), install the DHCP server role. Don't forget to authorize the servers in Active Directory.




On the server named DHCPsrv1 I have enabled certain Roles such as :AD DS, DNS and DHCP.

# I'm also going to show the server settings with some screenshots.

Type here to search




€ 4<mark>× 12:08 PM</mark>




These two screenshots show the domain settings for both servers, as can be seen, while the next step is to install DHCP Role.

"On the DHCP1 server, which is a member of the ita.lan domain, install the DHCP server role and configure the DHCP server with an address range (scope) from 192.168.201.101 to 192.168.201.151."

I'm starting this part of the task on the DHCPsrv1 Server, also in order not to include a lot of screenshots, I'll leave only the parts that are important for installing the roll:







As you can see, here is a screenshot of the installation process, the previous steps that I didn't show are standard.

- Before you begin, the default option is Next
- Installation Type opcija je Role based
- Server Selectetion is the selected local server DHCPsrv1
- Server Roles DHCP add Features
- If you don't want to use DHCP, then the next option is next.
- DHCP Server Option next
- Confirmation and the last one includes the result of the operation.


Since the DHCP role requires post-installation settings, the following screenshots include:






The procedure provided for DHCPsrv2 is identical and its settings in the task are provided for:

"On the DHCP2 server, which is also a member of the ita.lan domain (the server's IP address is 192.168.201.2), install the DHCP server role. Don't forget to authorize the servers in Active Directory.







# **DHCP MANAGEMENT**

In order to implement a DHCP failover, it is necessary to perform certain items beforehand.


"You need to implement DHCP failover."


On DHCPsrv1 I implement Scope, which is followed by the following screenshots:














"On the DHCP2 server, which is also a member of the ita.lan domain (the server's IP address is 192.168.201.2)"



# **CREATING A FAILOVER**

A replication failover must be performed using the following parameters:

• Partner server: 192.168.201.2

• Relationship Name: NameSurname (here you need to set your first and last name)


• Maximum Client Lead Time: 5 minute


• *Mode: Host Standby* 

• Role of partner server: Standby

Address reserved for standby server: 20%

Shared secret: 12345DHCP





The failover has been created, now I will show the details from the partner server that the failover was successful.

#### **POST-FAILOVER VIEW**

"On the DHCP2 server, in the DHCP console, under the IPv4 node, verify that Scope First Name is configured. Then, on the CLT-1 client computer (it must be logged on as a domain administrator), set the network adapter to automatically search for an IP address. Check the IP address of the DHCP server. After that, on the DHCP1 server, stop the DHCP service and restore the IP address on the CLT-1 client computer.

